

Rural 911 Sign Installation Instructions

Installation shall follow the parameters listed below.

Following the installation of a sign, the property owner shall provide a photo of the installation to buildingadmin@kawarthalakes.ca .

Upon receipt of the photo, Building and Septic Division staff will attend the property to confirm compliance of the installation. Should any issues be noted, the property owner will be given 30 days to correct and book a re-inspection.

- sign must be erected on the private property to which the number is assigned, NOT within the Municipal or Provincial Road allowance and NOT on the opposite side of the street;
- sign is to be erected within 1m of the property line adjacent to the street;
- sign is to be erected within 1m of the edge of the entrance laneway, on the driver's side of the laneway when entering the property;
- sign blade is to be affixed to a post (sign is predrilled under the green film);
- sign blade is to be affixed to the post perpendicular to the street which allows for the sign to be clearly read from the street when approaching from either direction;
- sign blade is to be erected between 1.2m and 1.8m above grade;
- sign blade must not be obscured by vegetation or any other landscaping or decorative items placed in the vicinity;
- Property Owner is responsible for sourcing and supplying the post and associated hardware, similar to:
 - Post: 7' Aluminum, or equivalent that will accept sign plate
 - Hardware: (2) ¼" x 1 ½" hex bolt – Zinc plated; (2) ¼" lock nut with Nylon insert – Zinc plated; (2) ½" flat washers – Zinc plated;

Remember to obtain locates prior to installation. Contact Ontario One Call at 1-800-400-2255 or complete an on-line form at ontarioonecall.ca

